



# Google Chromebook Pixel 2 Back Panel Replacement

This guide will help you remove and replace the back panel of your Chromebook.

Written By: Garrett Monteiro



## INTRODUCTION

This guide describes the necessary steps to remove the back panel of the device. This is a prerequisite for accessing all of the internal components of the device.

---




### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

## Step 1 — Back Panel



 Working on your device while it is turned on may result in electric shock. Make sure to shut down and unplug your device before you begin.

- Flip your device over so the bottom panel is facing up.

## Step 2



- Peel off the black rubber strips from top and bottom of the back panel.

## Step 3



- Remove the fifteen 3 mm Phillips #00 screws from the back panel.

## Step 4



- Carefully lift the back panel off of the device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-16 01:27:11 PM.

